


MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 INSTRUKCJA MONTAŻU
 ИНСТРУКЦИЯ СБОРКИ
 KÜCHEN SCHRÄNKE
 KITCHEN CABINET
 SZAFKI KUCZENNE
 КУХОННЫЙ ШКАФЪ








TYPE:L TYPE:R

D14 K


ST *fabryka mebli* LPLYT®

EXTOM
MEBLE







a1  8x35 x24	b0  x3	b1  x3	c1  Euro 4x13 x6	c3  Euro 6x13 x8
d2  x8	g0  x18	g1  7x50 x18	i2  4x16 x12	n1  3x16 x10
n2  3,5x16 x24	o1  x4	o2  x2	p0  x8	r4  x20
w  x2				



TYPE:L





TYPE:R





FOX GOLD



FOX BRONZE



FOX SILVER, SILVER+
FOX SILVER LUX,
FOX PLATINUM, PLATINIUM+



Klotz, Block, Griff, Handle,
Kłosek, Кубик, Uchwyt, Ручка

